

Torin T43004 Jack Stands w/Aluminum Blocks



The blocks on top of the Torin jack stands will fit into the jack points on BMW, MINI, Mercedes-Benz, and Nissan GT-R chassis. The jack stands are available with either a fixed block bolted to the saddle or a removable block held in place with a 10mm pin.

- 1) Remove the locking pins and collapse the jack stands to the lowest position.
- 2) Raise one end of the car from a factory recommended central jacking point until it is just above the desired height.
- 3) Raise the jack stands into the jack point pockets so that they are within 5mm to 8mm of the bottom of the pocket and re-insert the locking pin. This step is necessary since lowering the car more than 5mm to 8mm is likely to result in a misalignment of the jack point and jack stand. It may be necessary to adjust the height of the car with the floor jack since the jack stands can only be adjusted in 25mm increments.
- 4) Slowly lower the car the last 5mm to 8mm until it rests securely on the jack stands. Keep the floor jack positioned beneath the central jacking point.
- 5) Chock the wheels remaining on the ground.

It is a good idea to inspect the jack points on your car for damage from time to time. Replace damaged jack points or jack points with missing pins. Also, periodically clean out any accumulated road dirt from the jack points that could interfere with the jack stands.

PLEASE OBSERVE BASIC SAFETY PRECAUTIONS WHEN USING THE TORIN JACK STANDS.

- **ALWAYS USE JACK STANDS IN PAIRS. DO NOT SUPPORT THE CAR WITH ONE, THREE, OR FOUR JACK STANDS.**
- **LIFT THE END OF THE CAR FROM A CENTRAL JACKING POINT WITH A SUITABLE FLOOR JACK. DO NOT LIFT THE CAR ONE SIDE AT A TIME TO PLACE IT ON JACK STANDS.**
- **DO NOT LIFT THE CAR WITH AN EMERGENCY VEHICLE JACK TO PLACE IT ON JACK STANDS.**
- **RAISE THE CAR THE MINIMUM AMOUNT TO DO THE MAINTENANCE JOB AT HAND.**
- **CHOCK THE WHEELS REMAINING ON THE GROUND.**
- **REMOVE THE ALUMINUM BLOCKS BEFORE USING THE JACK STANDS WITH CARS THAT DO NOT HAVE JACK POINTS WITH AN INTEGRATED VEHICLE JACK POCKET.**

Reverse Logic Limited
103 Aubrey Lane
Royersford, PA 19468
www.reverselogic.us